

INSTRUCTION MANUAL

MOTOR PANASONIC GX FORCE FIT MOTOR PANASONIC GX FORCE FIT COASTER MOTOR PANASONIC GX ULTIMATE FIT

500041 | 500078 | 500042





NETWORKED CUSTOMISED INTELLIGENT Smartscale NewCo AG Luzernstrasse 84 CH-4950 Huttwil T+4162 959 53 00 info@fit-ebike.ch fit-ebike.com

TABLE OF CONTENTS

•	PREFACE	3
2	ABOUT THESE OPERATING INSTRUCTIONS 2.1 MANUFACTURER 2.2 EU IMPORTER 2.3 LANGUAGE 2.4 DECLARATION OF CONFORMITY 2.5 ON INFORMATION 2.6 WARNINGS IN THESE OPERATING INSTRUCTIONS	4
3	SAFETY INSTRUCTIONS 3.1 GENERAL INFORMATION	5
4	PRODUCT AND TECHNICAL SPECIFICATIONS 4.1 PANASONIC GX FORCE FIT ECO, PANASONIC GX FORCE FIT PRO, PANASONIC GX FORCE FIT PRO COASTER AND PANASONIC GX FORCE FIT ECO COASTER 4.2 PANASONIC GX ULTIMATE FIT ECO AND PANASONIC GX ULTIMATE FIT PRO 4.3 PROPER USE 4.4 IMPROPER USE 4.5 TECHNICAL DATA 4.5.1 PANASONIC GX FIT FORCE/PANASONIC GX FORCE FIT COASTER 4.5.2 PANASONIC GX ULTIMATE FIT	6 7 7
5	CLEANING AND SERVICING 5.1 CLEANING THE MOTOR	8
6	6.1.1 DRIVE SYSTEM OR DISPLAY DOES NOT START UP	9
7	11-21-2-11-2-11-2-2-2-2-2-2-2-2-2-2-2-2	11

1 PREFACE

Dear FIT customer,

The FIT system offers many useful functions and options and we are pleased that you have decided to choose our system.

Please read through the operating instructions carefully to ensure you use the system safely and get off to a quick start.

We hope you enjoy discovering the FIT's functions and have a fun ride every time you use it.

Thank you for placing your trust in FIT.

Your FIT Team

2 ABOUT THESE OPERATING INSTRUCTIONS

2.1 MANUFACTURER

Smartscale NewCo AG Luzernstrasse 84 CH-4950 Huttwil fit-ebike.com/en-en/

2.2 EU IMPORTER

Smartscale NewCo Europe GmbH Im Höning 5 DE-63820 Elsenfeld

2.3 LANGUAGE

The original operating instructions are written in German. A translation is invalid without the original operating instructions.

2.4 DECLARATION OF CONFORMITY

Biketec GmbH hereby declares that the products described in these operating instructions comply with EU directives. The complete EU Declaration of Conformity is available online at: fit-ebike.com/en-en/service/declaration/

2.5 ON INFORMATION

Different markings are used in the operating instructions to make them easier to read.

2.6 WARNINGS IN THESE OPERATING INSTRUCTIONS

Warnings indicate hazardous situations and actions. You will find the following warnings in the operating instructions:



DANGER

May lead to serious or even fatal injuries if ignored. Medium-risk hazard.



CAUTION

May lead to minor or moderate injuries if ignored. Low-risk hazard.



NOTICE

May lead to material damage if ignored.

3 SAFETY INSTRUCTIONS

3.1 GENERAL INFORMATION

Please read all safety instructions carefully. Failure to comply with the warnings or take residual risks into account may result in electric shock, fire and/or serious injury.

Keep the operating instructions in a safe place and have them readily available to consult. Pass these instructions on if you provide your e-bike for someone else's use.

The generic names used in these operating instructions, such as motor, battery and operating element, all refer to original FIT e-bike components.

3.2 DRIVE UNITS

Do not make any changes that affect the power or the maximum speed that the drive supports, especially to increase it. You may endanger yourself and others and you may be using your e-bike illegally in public spaces.

Do not open up the drive unit yourself. Only qualified technical staff may repair the drive unit and only with original spare parts. This ensures that the drive unit remains safe. Unauthorised opening of the drive unit will void the warranty.

All components fitted to the drive unit and all other e-bike drive components may only be replaced with components of an identical design or ones specifically approved by your e-bike's manufacturer. This protects the drive unit from overloading and damage.

When the push assist system is switched on, the pedals may possibly turn as well. When the push assist system is activated, make sure that you are at a sufficient distance from the rotating pedals. There is a risk of injury.

The brakes and the motor may become very hot during operation. There is a risk of burns or fire in case of contact. Never touch the brakes or the motor directly after a ride. Never place the e-bike on a flammable surface, such as grass or wood, or near flammable objects directly after use.

3.3 WHAT TO DO IN AN EMERGENCY

3.3.1 DANGEROUS SITUATION IN ROAD TRAFFIC

If you encounter any hazards or dangers in road traffic, apply the brake until the e-bike comes to a halt. The brake acts as an emergency stop system in such cases.

4 PRODUCT AND TECHNICAL SPECIFICATIONS

4.1 PANASONIC GX FORCE FIT ECO, PANASONIC GX FORCE FIT PRO, PANASONIC GX FORCE FIT PRO COASTER AND PANASONIC GX FORCE FIT ECO COASTER

Whether used for commuting in the city or excursions in the countryside, the Panasonic GX Force FIT provides riders with quiet, powerful assistance. Ideal for everyday use or longer trips with finely tuned assistance.



4.2 PANASONIC GX ULTIMATE FIT ECO AND PANASONIC GX ULTIMATE FIT PRO

Panasonic's dynamic GX Ultimate motors deliver great power for steep climbs and an effortless start on slopes. With high-performance assistance up to 300% and a torque up to 95 Nm, the steepest climbs become gentle, rolling hills.



4.3 PROPER USE

All check lists and instructions for actions in these operating instructions met. The drive unit is designed to supply power to the e-bike only and must not be used for other purposes.

4.4 IMPROPER USE

Improper use refers to use which is not described under **proper use** or goes beyond **proper use**.

4.5 TECHNICAL DATA

4.5.1 PANASONIC GX FIT FORCE/PANASONIC GX FORCE FIT COASTER



Electric drive		Panaonic GX Force FIT Eco Panaonic GX Force FIT Pro Panaonic GX Force FIT Eco Coaster Panaonic GX Force FIT Pro Coaster
Type		NUA233F (Eco) NUA233F (Pro)
		NUA234F (Coaster)
Part nos.		500041 (Eco)
		500041 & Upgrade 501058 (Pro)
		500078 (Eco Coaster)
		500078 & Upgrade 501058 (Pro
Ayla profila		Coaster) IIS 4-Kant
Axle profile Max. torque	Nm	60 (Eco)
Max. torque	IVIII	75 (Pro)
		60 (Coaster)
Nominal voltage	V	36
Operating temperature	°C	-10 to +40
Storage temperature	°C	-20 to +50
Weight about	kg	3,2

4.5.2 PANASONIC GX ULTIMATE FIT



Electric drive		PANASONIC GX Ultimate FIT Eco PANASONIC GX Ultimate FIT Pro
Туре		NUA230F (Eco)
		NUA230F (Pro)
Part nos.		500042 (Eco)
		500042 & Upgrade 501059 (Pro)
Axle profile		ISIS
Max. torque	Nm	70 (Eco)
·		95 (Pro)
Nominal voltage	V	36
Operating temperature	°C	-10 to +40
Storage temperature	°C	-20 to +50
Weight about	kg	2,95

CLEANING AND SERVICING 5

5.1 CLEANING THE MOTOR



CAUTION

- If water enters the motor, it will be permanently damaged.

 Never immerse the motor in water.

 Never clean with a pressure washer, water jet or compressed air.

 Never use cleaning agents.

 Carefully clean the motor with a soft, damp cloth.

6 TROUBLESHOOTING, FAULT CLEARANCE AND REPAIR

6.1 TROUBLESHOOTING AND FAULT CLEARANCE

6.1.1 DRIVE SYSTEM OR DISPLAY DOES NOT START UP

If the display and/or the drive system do not start up, proceed as follows:

- 1. Check if the battery is inserted correctly. If not, insert the battery correctly.
- 2. Start the drive system.
- 3. If the drive system does not start, remove the battery, check the charging status and charge if necessary.
- 4. Clean all contacts with a soft cloth.
- 5. Insert the battery.
- 6. Start the drive system.
- 7. If the drive system does not start, contact the specialist dealer.



NOTICE

If the battery terminal contacts are heavily soiled/oxidized. Take your e-bike to a specialist dealer for a detailed check.

6.1.2 ERRORS IN THE ASSISTANCE SYSTEM

Symptom	Cause	Remedy
Assistance is not available.	Is the speed too high?	 Check display screen. The motor assistance is only active up to the maximum speed for which the e-bike is approved.
	Is the battery charged sufficiently?	2. Check battery is charged.3. Recharge the battery if it is almost flat.
	The motor may become too hot	4. Switch off the drive system.
	during rides at high temperatures, up long inclines or when carrying a heavy load for a long time.	5. Wait a moment and then check again.
	The rechargeable battery, display or operating element may be connected incorrectly, or one or more of them may have a problem.	6. Contact your specialist dealer.
Assistance is not available.	Are the pedals being pushed?	1. Your e-bike is not a motorbike. Push the pedals
	Is the system switched on?	Press on-off button (operating element) to switch on the system.
	Is the level of assistance set to OFF ?	 3. Switch on the assistance by selecting an available assistance level (except OFF). 4. Contact your specialist dealer if you still feel that the no assistance is being supplied.

Symptom	Cause	Remedy
The assisted journey distance is too short.	The battery does not perform as well in winter weather.	This does not indicate a problem.
	The journey distance can be shorter depending on the road conditions, the level of assistance and the total light usage time.	 Check battery is charged. Recharge the battery if it is almost flat.
	Is the battery fully charged?	3. If the distance covered with a fully charged battery has become shorter, the battery may be affected. Replace the battery with a new one.4. If the distance you can cover with one single
	The battery is a consumable. Repeated charging and long periods of use cause the battery to degrade (loss of power).	charge is very short, replace the battery with a new one.
It is difficult to pedal.	Are the tires pumped to an adequate pressure?	1. Pump up tires.
	Is the level of assistance set to OFF ?	Switch on the assistance by selecting an available assistance level (except OFF).
	The battery charge might be low.	3. Check battery is charged.4. Recharge the battery if it is almost flat.
	Have you switched on the system with your foot on the pedal?	5. Switch on the system again without applying pressure to the pedals.6. If assistance is still not supplied, contact your specialist dealer.

6.2 REPAIR

Special expertise and tools are required for many repairs. That is why only a specialist dealer may perform repairs.

6.2.1 ORIGINAL PART

The individual e-bike parts have been carefully selected and matched to one other. Only original parts must be used for maintenance and repair. Observe the operating instructions for the new components.

7 RECYCLING AND DISPOSAL

7.1 DISPOSAL



Mechanical and electrical equipment, accessories and packaging should be recycled in an environmentally sound manner. Don't throw them in the garbage!



Only for EU countries: According to European Directives 2012/19/EU, 2006/66/EC and their transposition into national law, defective or unusable waste electrical and electronic equipment, rechargeable batteries and batteries must be collected separately and recycled in an environmentally sound manner.